

MISCELLANEOUS
 REAR SUSPENSION
 MINX - HUSKY

No. 201

September 26, 1960

TO ALL ROOTES GROUP DEALERS

Rectification of the above complaint can be achieved by fitting a packing piece to the top of the right hand rear spring (HIGH SIDE). This has been fitted in production on later models.

On Minx cars it is necessary to change the right hand rear spring 'U' bolts and dowel bolt sleeve.

On Husky and Commer Cob cars it is necessary to change the original dowel bolt. The existing 'U' bolts are of sufficient length to take the extra thickness of the packing piece.

The new parts required are available under the following Part Numbers:-

MINX

| | | |
|---------------------|---------|------------------|
| Packing rear spring | 1208049 | |
| Sleeve | 9088175 | |
| 'U' bolt (2 req'd) | 9009020 | (Sal. and Coupe) |
| 'U' bolt (2 req'd) | 9009083 | (Estate) |

HUSKY AND COMMER COB

| | |
|---------------------|---------|
| Packing rear spring | 1207428 |
| Dowel bolt (Husky) | 5220325 |
| Dowel Bolt (Cob) | 5220326 |

Fitting Instructions (Minx)

Remove the existing 'U' bolts and separate the right hand rear spring from the rear axle. (It is not necessary to remove the spring assembly from the chassis).

Remove the dowel bolt sleeve. Insert the new sleeve and the packing piece (the hole in the center of the packing piece fits over the sleeve).

Fit new 'U' bolts.

Reconnect the spring to the axle.

Kindly bring this to the attention of all Service personnel.

Fitting Instructions (Husky and Cob)

Remove and dismantle the spring.

Reassemble the spring leaves and secure with the new dowel bolt.

Fit the packing piece to the top of the spring assembly (the hole in the packing piece fits over the dowel bolt head).

Refit the spring assembly.