

March, 1965

TO: ALL ROOTES DEALERS
MODEL: SUNBEAM IMP
SUBJECT: NO DRAUGHT VENTILATORS

The design of the no draught ventilators fitted to the Imp has recently been modified. The earlier type of no draught ventilator with peg type upper pivot can be serviced with the later type components.

When fitting a new inner frame to an old outer frame, it is necessary to fit a new top pivot to the outer frame. This can be fitted in the original location using the original screws. Secure the pivot, using a new spacer and pivot pin. Carefully trim the old type weatherstrip to suit the new top pivot.

When fitting a new outer frame to an old inner frame, use the original type of top pivot either new or as removed from the displaced assembly.

Both new and old weather strips are serviced and should be ordered accordingly.

Part Number changes are as follows:-

7096060	Inner Frame C/W Glass O/S	replaces 7204196
7096061	Inner Frame C/W Glass N/S	replaces 7204197
7096059	Glass	replaces 7204201
7096062	Outer Frame O/S	replaces 7096006
7096063	Outer Frame N/S	replaces 7096005
7096058	Channel	replaces 7204200
7205086	Top Pivot O/S	replaces 7204208
7205087	Top Pivot N/S	replaces 7204209
7096064	Weatherstrip O/S	replaces 7204194
7096065	Weatherstrip N/S	replaces 7204195
7205090	Spacer - Additional	
7080234	Pivot Pin - Additional	

ROOTES MOTORS INCORPORATED

Kenneth Langridge
Kenneth Langridge
General Service Manager